

# Using Preservation Metrics

**James M. Reilly**

**University of Texas at Austin, School of Information, Austin, TX  
September 16-17, 2010**




NATIONAL  
ENDOWMENT  
FOR THE  
HUMANITIES



# What Are Preservation Metrics?

- Algorithms (step by step instructions for computers) for transforming T & RH data into meaningful conclusions
- Developed by IPI and implemented in IPI-created software and web sites
- Yield numerical estimates of the risks of environmentally-induced decay



# Why Have Preservation Metrics?

- Address shortcomings of subjective ‘eyeball’ analysis of graphical data or summary statistics
  - Axis scaling
  - Inconsistencies
  - Target ranges for T & RH may not have been thoughtfully set
- Need for analysis based collection risks



# Why Have Preservation Metrics?

- Standardized, repeatable
- Allow for
  - Room to room comparisons
  - Incremental improvements
  - Demonstrating progress and stewardship
  - Make fast work of analysis of large amounts of data
  - Non-experts to do good analysis

# Real-World Analysis

- Targets and statistics are enough for engineers and building operators
  - But not for collections care
- In practice, both targets and metrics are useful
  - But not at all mutually exclusive

# Using Metrics in Practice

- Learn a few ‘rules of thumb’ to help interpret the numbers
- Invest a little time to understand what the metrics are telling you
- Remember, the metrics describe environments in preservation terms
  - But YOU have to know the vulnerabilities of your collection



# IPI Preservation Metrics

- Chemical Change (Natural Aging)
  - Preservation Index (PI)
  - Time-Weighted Preservation Index (TWPI)
- Applies to:
  - Organic materials (paper, leather, plastics, dyes, textiles)
- Concept
  - Integrate heat and moisture over time to estimate natural aging rate

# Natural Aging: PI vs. TWPI

- PI (Preservation Index)
  - IPI has assigned a number (the PI) to every combination of T & RH
  - Higher is better, means longer life and slower decay
- PI values describe a static, unchanging condition

# Natural Aging: PI vs. TWPI

- TWPI (Time-Weighted Preservation Index)
  - Integrate PI values over a period of time
  - ‘Averages’ them correctly
- Most useful when analyzing a full years’ data
- Most significant metric for library and archive collections

Type of Decay:  
**Natural Aging**

**Metrics Used:**

Time Weighted Preservation Index (TWPI)

**Interpretation:**

Higher the TWPI, the better

**Measures:**

The rate of "natural aging" as determined by the rate of spontaneous chemical change in organic materials.

TWPI Value (years)	Interpretation
≥75	Good
45-75	OK
≤45	RISK

# IPI Preservation Metrics

- Mechanical Risk Metrics
  - Dryness & Dampness extremes - % EMC
  - Fluctuation extreme - % DC
- Applies to
  - Hygroscopic materials (wood, paper, leather, textiles)
- Concept
  - Physical Risks arise from extremes of dryness and dampness, excursions between extremes

Type of Decay:  
**Mechanical Damage**

**Metrics Used:**

- Minimum % Equilibrium Moisture Content (min % EMC)
- Maximum % Equilibrium Moisture Content (max % EMC)
- % Dimensional Change (% DC)

% Min EMC, % Max EMC and % DC	Interpretation
Min EMC > 5.0 AND Max EMC < 12.5 AND DC < 0.5	<b>Good</b>
Min EMC > 5.0 AND Max EMC < 12.5 AND DC < 1.5	<b>OK</b>
Min EMC < 5.0 OR Max EMC > 12.5 OR DC > 1.5	<b>RISK</b>

**Interpretation:**

Moderate % EMC is best ==> % EMC between 5% and 12 % maintains appropriate levels of moisture  
 The lower % DC, the better ==> fewer, smaller fluctuations between maximum EMC and minimum EMC



# IPI Preservation Metrics

- Mold Risk
  - Mold Risk Factor (MRF)
- Applies to:
  - Anything that mold can grow on
- Concept
  - Integrates T & RH over time
  - Estimates whether mold spores would germinate and overall severity of mold outbreak

Type of Decay:  
**Mold Growth**

**Metrics Used:**

Mold Risk Factor (MRF)

**Measures:**

The risk for growth of the xerophilic mold species on collection objects or in collection areas.

Mold Risk Factor	Interpretation
$\leq 0.5$	Good
$> 0.5$	RISK

# IPI Preservation Metrics

- Metal Corrosion
  - % EMC Max
- Applies to:
  - Ferrous and other metals
- Concept
  - RH sustained above 55% for 30 days or more causes corrosion

Type of Decay:  
**Metal Corrosion**

**Metrics Used:**

Maximum Equilibrium Moisture Content (% EMC max)

**Interpretation:**

Lower % EMC is better

% EMC (max)	Interpretation
$\leq 7.0$	Good
$\geq 7.1$ and $\leq 10.5$	OK
$\geq 10.6$	RISK

# Metrics in Practice

- How can I analyze my data with the IPI Metrics?
  - [www.PEMData.org](http://www.PEMData.org)
    - PEM and PEM2 files
    - Climate Notebook .dbf files
  - IPI's Climate Notebook software
    - [www.imagepermanenceinstitute.org](http://www.imagepermanenceinstitute.org)

Home Metrics

Graphs

Statistics

Preservation Metrics

Collection Risks

Dew Point Calculator

Preservation Quality Analysis - Based on observed environmental conditions, but independent of the collections within the space.

## Date Range

Preset: All

Start: 2008-01-01

End: 2008-06-19

## Datasets

(Max 5 per graph):

 AL-AUBURN-2008 archives hall archives library archives main archives media P2\_00051 P2\_00278 P2\_00279 P2\_00298

Dataset	archives library	P2_00051	P2_00278	P2_00279	P2_00298
<b>Risk Summary</b>					
Natural Aging	RISK	RISK	RISK	RISK	RISK
Mechanical Damage	OK	RISK	RISK	RISK	OK
Mold Growth	Good	Good	RISK	Good	Good
Metal Corrosion	OK	RISK	RISK	RISK	RISK
<b>Preservation Metrics</b>					
TWPI	44	39	41	40	37
MRF	0	0.44	0.85	0.11	0.04
% DC Max	0.65	1	1.2	0.88	0.76
% EMC Min	7.4	10.1	10	9.8	8.6
EMC Max	9.7	13.7	14.2	12.9	11.4
EMC Mean	8.53	11.31	11.35	10.84	9.7
<b>Data Overview</b>					
Start	2008-03-14	2008-03-13	2008-03-13	2008-03-13	2008-03-14
End	2008-03-28	2008-06-18	2008-06-18	2008-06-18	2008-06-18
T°F <sub>mean</sub>	70.1	65.6	65.3	66.4	69.8
% RH <sub>mean</sub>	38.9	63	63.2	60.4	54.2
DP°F <sub>mean</sub>	42.9	52.2	51.8	51.8	51.9

Email | Print | Full Screen